


POWER Unit

1 2 3 4 5 6 7 8 9 10

△ AND SHADED COMPONENTS=SAFETY RELATED PARTS



LD	1	INV24V
	2	INV24V
	3	INV24V
	4	INV24V
	5	INV24V
	6	GND
	7	GND
	8	GND
	9	GND
	10	GND
	11	NC
	12	NC
LA	1	INV24V
	2	INV24V
	3	INV24V
	4	INV24V
	5	INV24V
	6	GND
	7	GND
	8	GND
	9	GND
	10	GND
	11	GND/NC
	12	INV-ON
	13	INV-BRT
	14	SEL
PC	1	S24V
	2	S24V
	3	S24V
	4	NC
	5	GND
	6	GND
	7	GND
PA	1	UR35V
	2	GND
	3	GND
	4	UR13V
	5	UR13V
	6	UR13V
	7	GND
	8	GND
	9	GND
	10	UR5V
	11	UR5V
	12	UR5V
	13	UR5V
	14	UR5V
	15	UR5V
	16	GND
	17	GND
	18	GND
	19	GND
	20	BUSV
	21	BUSV
	22	GND
	23	GND
PB	1	P-CON1
	2	P-CON2
	3	GND
	4	INV-ON
	5	INV-BRT
	6	POWER-DET
	7	FAN-ERR2
	8	LCD-POW
	9	SEL